


Invasive Ductal Carcinoma Classification



Team

Alessandro
Tiveron

- Implementation of original project with fasAI library

Francesco
Ferronato

Mattia
Tortelli

Francesca
Virgolini

Niccolò
Brusadin



Index

- Description of the Original Project
- Limitations of the Original Project
- Objective
- Method
- Results




Data Overview and Task

Original Dataset: 162 whole-mount slide images of Breast Cancer specimens

Patch Extraction: 277,524 patches (50 x 50 pixels)

Class Distribution:
198,738 IDC negative
78,786 IDC positive




Filename Format:
u_xX_yY_classC.png

- u: Patient ID (e.g., 10253_idx5)
- X: x-coordinate of patch
- Y: y-coordinate of patch
- C: Class (0 for non-IDC, 1 for IDC)

Objective: Classify patches into IDC negative (0) and IDC positive (1) using fastAI and CNN

Challenge: Utilize the dataset to develop a robust model for accurate Breast Cancer classification



Description of the Original Project

Methodology:

- FastAI implementation of Transfer Learning Approach

Data Exploration:

- Organized Kaggle dataset into patient folders
- Each patient folder contains 2 subfolders 'class 0' and 'class 1'

Data Loading:

- ImageDataBunch setup with validation, augmentation, and normalization

Transfer Learning:



- Adopted pre-trained ResNet18 on ImageNet
- Focus on fine-tuning last layer

Model Implementation:

- Implemented with `cnn_learner()` using pre-trained ResNet18

Learning Rate Optimization:

- Optimized using `lr_find()`, one-cycle training, and refined learning rates





Results

Performance of model trained with
fit_one_cycle policy (for 1 epoch??)
(Ale?)

epoch	train_loss	valid_loss	accuracy	time
0	0.311559	0.409009	0.879324	08:59

Performance improved after unfreezing
and optimizing hyperparameters

epoch	train_loss	valid_loss	accuracy	time
0	0.282195	0.790487	0.889035	09:19



Limitations of the Original Project


Outdated
fastAI library
version

Data
preparation

Lack of test
set

Unbalanced
classes

Training data/validation/test




V7 Labs

Objective

- Understanding the original project
- Transition from fastAI to Keras
- Implement the latest fastAI libraries
- Enhance robustness with a test set, balance classes
- Exploring ResNet50's potential

Keras ResNet⁵⁰



Methods: Pre-training



Library Utilization:

A Keras user-friendly implementation (to control data augmentation and preprocessing)



Data Preprocessing:

Organizing histopathology images into 70% training and 15% validation and 15% test set



Class Imbalance Handling:

Weights assigned to prioritize correct classification of class 1



Augmentation and Preprocessing:

With RandomFlip(), RandomRotation() and RandomZoom()

Methods: Model Training optimization



1. Finding Optimal Learning Rate

Identify the best learning rate for model training.



2. Unfreezing Model Parameters

Unlock all hyperparameters for comprehensive training



3. Re-evaluating Learning Rate Post-Unfreezing

Reassess the optimal learning rate after unfreezing parameters



4. Fine-Tuning

Define model convergence with unfrozen parameters

Methods: Models



Transfer Learning with EfficientNetV2S:

EfficientNetV2S, pretrained on ImageNet, as first model implementation



Transfer Learning with ResNet50:

Exploration of ResNet50 for binary classification as an alternative approach




Performance Evaluation:

Predictions and evaluation on an external test set after 5 epochs



Results



- Performance of EfficientNetV2s on test set



	precision	recall	f1-score	support
0	0.924	0.802	0.858	19874
1	0.625	0.833	0.714	7879
accuracy			0.811	27753
macro avg	0.774	0.818	0.786	27753
weighted avg	0.839	0.811	0.818	27753

Results






- Examples of cancer classification
(Attendo immagini del codice
runnato)



Results

- Performance on test set of ResNet50 trained for # epochs

	precision	recall	f1-score	support
0	0.953	0.841	0.893	4138
1	0.687	0.893	0.777	1622
accuracy			0.855	5760
macro avg	0.820	0.867	0.835	5760
weighted avg	0.878	0.855	0.860	5760





Conclusion (da confermare)



High Accuracy with ResNet50:

ResNet50 demonstrates precision in predicting IDC and non-IDC cases as original project



Improved Robustness:

Results are significantly enhanced with the implementation of a dedicated test set and balanced classes